Adding Sounds to My Favorites and Creating My Hunts

Alpha Dogg and Turbo Dogg

My Favorites

- 1. Select My Favorites
- 2. Push the Hot 1 (Alpha) or Right (Turbo) button
- 3. Scroll to desired sound from list, push select to add
- 4. Back out to My Favorites and repeat the process for each sound you would like to add

My Hunts

- 1. Select My Hunts
- 2. Push the Hot 1 (Alpha) or Right (Turbo) button to create new hunt
- 3. Use the arrows to create a name for your new hunt
- 4. Push the Select button to save the name
- 5. Push the Hot 1 (Alpha) or Right (Turbo) button to add a sound
- 6. Scroll to desired sound and choose by pushing Select
- 7. Repeat steps 5 and 6 for each desired sound
- 8. Once all sounds are added, push the 2 button (Alpha) or Menu button (Turbo) to save your hunt

NOTE: You MUST add sounds in the order you want them to play. You will not be able to change the order after adding the sounds.

